

Quantum QA Series

Air-to-water heat pump



Installation and user handbook

QCH 2346-
123456

CONTENTS

1 Important information.....	3
General.....	3
Safety.....	3
Symbols.....	4
Product labels.....	4
Serial number and QR code.....	4
Environmental information.....	4
Glossary.....	4
2 Before installing.....	5
Transport.....	5
Installation area.....	5
Supplied components.....	5
Access.....	6
3 Components.....	7
Overview.....	7
Connections.....	7
Electrical box.....	7
4 Electrical installation.....	8
General.....	8
5 Commissioning.....	9
6 Comfort disturbance.....	10
Troubleshooting.....	10
7 Technical specifications.....	12
Sound levels.....	12
Dimensions.....	12
Operational data.....	12
Technical data.....	12
Energy labelling.....	13
Index.....	16

1 IMPORTANT INFORMATION

General

ⓘ WARNING

Read this manual before starting the heat pump for the first time.

It is the owner of the heat pump that is responsible for the system. If you suspect that the product is defective, contact your dealer.

Safety

This manual contains installation and servicing procedures that must be performed by a professional.

The manual must be available for people who install, support or use the heat pump.

⚠ CAUTION

This appliance can be used by children from 8 years and above and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children must not play with the appliance. Cleaning and maintenance must not be performed by children unless they are older than 8 and supervised.

R290 refrigerant

R290, a flammable refrigerant, is present in the product. In the event of a leak, leaking refrigerant might combine with air and create an environment that could catch fire.

ⓘ WARNING

It is prohibited to expose the product to flammable gases or liquids as it may cause fire.

ⓘ WARNING

The unit must not be placed close to flammable gas. Fire may start if there is a gas leak of any kind.

ⓘ WARNING

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

Safe area


ⓘ WARNING

The heat pump must be installed outdoors. The unit must be installed so that, in the event of a leak, refrigerant cannot enter the building.

The safe area stretches from the top of the heat pump to ground level (H1 in the following image) and one meter in all directions from the edges of the unit.


👉 NOTE

The safe area is not to be mistaken for the allowed installation area.




Windows, doors, ventilation openings, and potential ignition sources must not be present in the safe area. The safe area extends into neighboring structures. All wall penetrations in outer walls must be gas-tightly sealed.

The installation depicted in the following image is incorrect with relation to the safe area.



The installation depicted in the following image is allowed with relation to the safe area.



The equipment contains R290, a fluorinated greenhouse gas with a global warming potential (GWP) of 1. Do not release R290 into the atmosphere.

Recycling



At the end of the electrical products useful life, it must not be disposed of with household waste.

Recycle at waste facility. Check with your local authority or retailer for local recycling regulations.

Glossary

The following terms are used throughout the manual to describe various functions of Quantum QA.

Distribution system

The distribution system is the system that is used to provide the house with heating through radiators, floor heating and/or fan convectors.

Hydronic unit

The hydronic unit consists of an accumulator tank, pipe connections, electrical connections and the graphical user interface. It provides the house with domestic hot water as well as heating through the distribution system.

Symbols

The manual contains the following symbols

⚠ WARNING

This symbol describes information that is of great danger to people or equipment.

⚠ CAUTION

This symbol describes information that could cause danger to people or equipment.

👉 NOTE

This symbol describes information that is crucial when installing or servicing the heat pump.

ℹ TIP

This symbol describes information that can be helpful when installing or servicing the heat pump.

Product labels

These labels are found on the product.

CE CE marking indicates that a product has been assessed by the manufacturer and deemed to meet EU safety, health and environmental protection requirements.

IP21 Protection classification against water and dust in the electrical enclosure.

Serial number and QR code

Environmental information


F-gas regulation (EU) No. 517/2014

This product contains a fluorinated greenhouse gas that is covered by the Kyoto protocol.

2 BEFORE INSTALLING

Transport

Transport Quantum QA in an upright position. Ensure that the unit is adequately secured so it does not fall during transit.



If using a trolley or hand truck when moving the heat pump, always have the heat pump standing on the pallet.


Installation area

Measurements

When installing QA, ensure that there is enough room for the inlet and outlet air. There must be at least 500 mm of free space behind and 1500 mm in front of the heat pump. For servicing purposes, there must be at least 1000 mm of free space to the right and 500 mm to the left of the heat pump.

NOTE

Consider the height of obstacles surrounding the heat pump. High walls or other barriers can cause resonant sounds and unwanted recirculation of cold air.



Prerequisites

Install the heat pump in accordance with the following requirements.

NOTE

If the heat pump is placed on concrete slabs, the slabs must rest on shingles or asphalt.


Place the heat pump on a solid surface that can withstand the weight of the heat pump.

- Do not place the heat pump directly on a lawn or a similar non-solid surface.
 - Place the heat pump on a concrete base, concrete slabs or equivalent.
- Ensure that the installation area is adequately ventilated.

NOTE

In case of leakage, the refrigerant must not enter the house through ventilation openings, doors or windows.

- Ensure that the installation area is free from heat radiation, fire hazards and ignition sources.
- Do not position the heat pump next to a noise sensitive wall.
- Ensure that the bottom of the evaporator is positioned higher up than the average level of snow depth.
- Ensure that condensing water is led away from the heat pump.
- If there is a risk of snow falling onto the heat pump, protect the heat pump by installing adequate snow protection.



Supplied components


The supplied components package contains the following items.

- Vibration dampers (4 pcs)
- Temperature sensor
- Screws (4 pcs)
- 4-core signal cable
- Condensing water collector (2 pcs)
- Wire controller


Access

This section describes how to access the electrical connections in the heat pump.

1. Hold the electrical cover in place.
2. Release the screws at the bottom of the electrical cover.



3. Slide the electrical cover downwards.
4. Remove the electrical cover from the heat pump.



3 COMPONENTS

Overview

Connections

Electrical box

DRAFT

4 ELECTRICAL INSTALLATION

General


ⓘ WARNING

All electrical connections must be performed by a qualified electrician and in accordance with applicable regulations.


Access

This section describes how to access the electrical connections in the heat pump.

1. Hold the electrical cover in place.
2. Release the screws at the bottom of the electrical cover.



3. Slide the electrical cover downwards.
4. Remove the electrical cover from the heat pump.



5 COMMISSIONING

DRAFT

6 COMFORT DISTURBANCE

Troubleshooting

Before troubleshooting

If the system does not inform about an active fault, check the following components before troubleshooting.

⚠ WARNING

The incoming supply electricity must be isolated at the safety switch by or under the supervision of a trained electrician in the event that corrective action is needed to address faults that call for work inside screwed hatches.

- Power supply.
- Group and main fuses of the property.
- Residual current device (RCD).
- Internal fuse in the hydronic unit.
- Internal temperature limiter in the hydronic unit.
- That the air flow to the heat pump is not obstructed.

The heat pump does not start

An alarm is active

- Check the display unit of the hydronic unit for information about possible alarms.

No demand is active

- Heating or hot water production is not requested by the hydronic unit.

The compressor is blocked due to temperature limitations

- Ensure that the heat pump is not outside its operational range.

Not enough time has passed since the previous compressor start

- Wait for approximately 30 minutes and see if the compressor starts.

No communication with hydronic unit

Erroneous connection of communication

- Ensure that the communication cable is correctly installed.

Erroneous set-up in hydronic unit

- Ensure that the heat pump is correctly set up in the hydronic unit.

Unsatisfactory hot water production

Increased hot water production

- Wait until the target temperature for the hot water has been reached.

Erroneous hot water settings

- Check and, if necessary, change the hot water settings in the hydronic unit.

Obstructed particle filter

- Turn off the power supply to the heat pump and clean the particle filter.

Low room temperature

Insufficient flow in distribution system

- Fully open several or all thermostats.

Erroneous room temperature settings

- Check, and if necessary, change the room temperature settings in the hydronic unit.

Air in distribution system

- Vent the distribution system.

Low compressor frequency

- Check the compressor frequency and make sure that the compressor parameters are adjusted properly.
 - a) If adjusting the compressor settings is not possible or insufficient, contact a service technician.

Fan is not running or is running too slowly

- Adjust the fan speed parameters.
 - a) If adjusting the fan speed settings is not possible or insufficient, contact a service technician.

Refrigerant leakage

- Check the exhaust temperature and the refrigerant pressure.
 - a) If a leakage is present, contact a service technician.

High room temperature

Erroneous room temperature settings

- Check, and if necessary, change the room temperature settings in the hydronic unit.

The display is not powering up

This error description is only applicable for units with an internal display unit.

Electrical connections are not installed correctly

- Ensure that the display cable is installed correctly.
- In three-phase installations, ensure that the phases are connected in the right phase sequence.

Unresponsive display unit

This error description is only applicable for units with an internal display unit.

The display is locked

- Check if a locked icon is visible in the display unit and unlock if necessary.

The display is broken

- Ensure that the display cable is installed correctly.
- Disconnect and reconnect the power supply cable.

Frost build-up on evaporator due to insufficient defrosting

Erroneous defrosting settings

- Check the defrosting settings.

Faulty EEV (electronic expansion valve)

- Ensure that the EEV works as expected.
 - a) If there is a fault on the EEV, contact a service technician.

Insufficient air flow over the evaporator

- Check the fan and the fan speed settings.

Refrigerant amount issue

- Check the exhaust temperature and the refrigerant pressure.
 - a) If a leakage is present, contact a service technician.

Low compressor frequency

- Check the compressor frequency and make sure that the compressor parameters are adjusted properly.
 - a) If adjusting the compressor settings is not possible or insufficient, contact a service technician.

Abnormal noise

Unfastened screws

- Ensure that all screws are properly fastened.

Fan blade or fan motor

- Ensure that the fan is functioning correctly and is firmly mounted.

Compressor


- Ensure that the compressor is functioning correctly and is firmly mounted.

Adjoining components

- Ensure that sound does not travel because of touching components.

7 TECHNICAL SPECIFICATIONS

Sound levels




	QA-6	QA-9
Sound power level, $L_w(A)_{EN12102}$	57	57
Sound pressure levels¹		
At 1 m	52	52
At 2 m	46	46
At 3 m	42	42
At 4 m	40	40
At 5 m	38	38
At 6 m	36	36

	QA-6	QA-9
At 7 m	35	35
At 8 m	34	34
At 9 m	33	33
At 10 m	32	32

¹ Sound pressure levels are calculated using directivity factor Q=4.

Dimensions

Operational data



Technical data

MODEL		QA-9	QA-15 (1-PHASE)	QA-15 (3-PHASE)
Energy efficiency, average climate				
The product's efficiency class room heating, average climate 35 / 55 °C			A+++/A+++	
The system's efficiency class room heating, average climate 35 / 55 °C			A+++/A+++	
Output data (EN14825)				
Nominal heating output ($P_{design,h}$)	kW	5	10	10
SCOP average climate, 35 °C / 55 °C		5,16 / 3,85	5,05 / 3,88	5,05 / 3,88
Heating capacity and COP¹				
Heating capacity / COP (min)	kW		5,34 / 5,09	5,34 / 5,09
Heating capacity / COP (nominal)	kW		10,35 / 4,91	10,35 / 4,91
Heating capacity / COP (max)	A		15,37 / 4,53	15,37 / 4,53
Refrigerant circuit				
Type of refrigerant (GWP)		R290 (3)		
CO ₂ equivalent	kg	1,5	2,55	2,55
Refrigerant quantity	kg	0,5	0,85	0,85
Cut-out value pressostat LP	MPa/bar	0,8/80		
Cut-out value pressostat HP	MPa/bar	3,0/300		
Heating medium circuit				
Operational range	°C	-25~43		
Max external available pressure	kPa	74		
Air flow				
Maximum air flow	m ³ /h	??	??	??
Electrical data				
Rated voltage	V	230V 1N ~ 50Hz	230V 1N ~ 50Hz	400V 3N ~ 50Hz
Maximum power input	kW	3,0	5,3	5,3
Maximum current input	A	13,5	24,5	10,5

MODEL		QA-9	QA-15 (1-PHASE)	QA-15 (3-PHASE)
Recommended fuse	A	16		
Enclosure class		IPX4		
Sound data				
Sound power level (L _{W(A)}) _{EN12102}	dB	57	57	58
Sound pressure level (1m)	dB(A)	42	43	44
Fan data				
Fan motor type		DC motor		
Fan motor power input (min~max)	W	55~105	60~120	60~120
Fan speed	rpm	300~600	220~600	220~600
Connection dimensions				
Heating medium, external thread ø	inch	1	1	1
Weight and dimensions				
Net weight	kg	80	160	160
Heat pump dimensions (W x D x H)	mm	1167 x 407 x 795	1287 x 458 x 928	1287 x 458 x 928

¹ Ambient temperature: 7°C, supply temperature: 35°C

Energy labelling

Information sheet

SUPPLIER		QVANTUM	QVANTUM
MODEL		QA-5	QA-9
Temperature application	°C	35 / 55	35 / 55
Seasonal space heating energy efficiency class, average climate		A+++ / A+++	A+++ / A+++
Rated heat output (P _{designh}), average climate	kW	5,0 / 4,8	9,5 / 9,0
Annual energy consumption space heating, average climate	kWh	1970 / 2575	3823 / 4710
Seasonal space heating energy efficiency, average climate	%	205 / 150	202 / 156
Sound power level L _{WA} indoors	dB	-	-
Sound power level L _{WA} outdoors	dB	57 / 60	56 / 57

Data for energy efficiency of the package

MODEL		QA-9	QA-15
Temperature application	°C	35 / 55	35 / 55
Controller, class		IV	IV
Controller, contribution to efficiency	%	4	4
Seasonal space heating energy efficiency of the package, average climate	%	209 / 154	206 / 160
Seasonal space heating energy efficiency class of the package, average climate		A+++ / A+++	A+++ / A+++

Technical documentation

MODEL	QA-9						
Type of heat pump	<input checked="" type="checkbox"/> Air-water <input type="checkbox"/> Exhaust-water <input type="checkbox"/> Brine-water <input type="checkbox"/> Water-water						
Low-temperature heat pump	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No						
Integrated immersion heater for additional heat	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No						
Heat pump combination heater	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No						
Climate	<input checked="" type="checkbox"/> Average <input type="checkbox"/> Cold <input type="checkbox"/> Warm						
Temperature application	<input checked="" type="checkbox"/> Medium (55°C) <input type="checkbox"/> Low (35°C)						
Applied standard	EN14825, EN14511, EN12102						
Rated heat output	Prated	4,77	kW	Seasonal space heating energy efficiency	η _s	150,1	%
Declared capacity for space heating at part load and at outdoor temperature T _j				Declared coefficient of performance for space heating at part load and at outdoor temperature T _j			
T _j = -7 °C	Pdh	4,2	kW	T _j = -7 °C	COPd	2,33	-
T _j = +2 °C	Pdh	2,7	kW	T _j = +2 °C	COPd	3,68	-
T _j = +7 °C	Pdh	2,6	kW	T _j = +7 °C	COPd	5,07	-
T _j = +12 °C	Pdh	3,0	kW	T _j = +12 °C	COPd	7,35	-
T _j = biv	Pdh	4,2	kW	T _j = biv	COPd	2,33	-
T _j = TOL	Pdh	4,73	kW	T _j = TOL	COPd	2,08	-
T _j = -15 °C (if TOL < -20 °C)	Pdh		kW	T _j = -15 °C (if TOL < -20 °C)	COPd		-

MODEL		QA-9					
Bivalent temperature	T _{biv}	-7	°C	Min. outdoor air temperature	TOL	-10	°C
Cycling interval capacity	P _{cy}		kW	Cycling interval efficiency	COP _{cy}		-
Degradation coefficient	C _{dh}	0,99	-	Max supply temperature	WTOL	75	°C
<i>Power consumption in modes other than active mode</i>				<i>Additional heat</i>			
Off mode	P _{OFF}	0.010	kW	Rated heat output	P _{sup}	0,0	kW
Thermostat-off mode	P _{TO}	0.010	kW				
Standby mode	P _{SB}	0.010	kW	Type of energy input	Electric		
Crankcase heater mode	P _{CK}	0.042	kW				
<i>Other items</i>							
Capacity control	Variable			Rated airflow (air-water)		2500	m ³ /h
Sound power level, indoors/outdoors	L _{WA}	- / 60	dB	Nominal heating medium flow			m ³ /h
Annual energy consumption	Q _{HE}	2575	kWh	Brine flow brine-water or water-water heat pumps			m ³ /h
Contact information	Qvantum Energi AB - Ji-te gatan 7 - 265 38 Åstorp - Sweden						

MODEL		QA-9					
Type of heat pump	<input checked="" type="checkbox"/> Air-water <input type="checkbox"/> Exhaust-water <input type="checkbox"/> Brine-water <input type="checkbox"/> Water-water						
Low-temperature heat pump	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No						
Integrated immersion heater for additional heat	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No						
Heat pump combination heater	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No						
Climate	<input checked="" type="checkbox"/> Average <input type="checkbox"/> Cold <input type="checkbox"/> Warm						
Temperature application	<input checked="" type="checkbox"/> Medium (55°C) <input type="checkbox"/> Low (35°C)						
Applied standard	EN14825, EN14511, EN12102						
Rated heat output	Prated	9,03	kW	Seasonal space heating energy efficiency	η _s	155,5	%
<i>Declared capacity for space heating at part load and at outdoor temperature T_j</i>				<i>Declared coefficient of performance for space heating at part load and at outdoor temperature T_j</i>			
T _j = -7 °C	P _{dh}	8,0	kW	T _j = -7 °C	COP _d	2,41	-
T _j = +2 °C	P _{dh}	4,9	kW	T _j = +2 °C	COP _d	3,77	-
T _j = +7 °C	P _{dh}	5,8	kW	T _j = +7 °C	COP _d	5,38	-
T _j = +12 °C	P _{dh}	6,5	kW	T _j = +12 °C	COP _d	7,07	-
T _j = biv	P _{dh}	8,0	kW	T _j = biv	COP _d	2,41	-
T _j = TOL	P _{dh}	9,2	kW	T _j = TOL	COP _d	2,02	-
T _j = -15 °C (if TOL < -20 °C)	P _{dh}		kW	T _j = -15 °C (if TOL < -20 °C)	COP _d		-
Bivalent temperature	T _{biv}	-7	°C	Min. outdoor air temperature	TOL	-10	°C
Cycling interval capacity	P _{cy}		kW	Cycling interval efficiency	COP _{cy}		-
Degradation coefficient	C _{dh}	0,99	-	Max supply temperature	WTOL	75	°C
<i>Power consumption in modes other than active mode</i>				<i>Additional heat</i>			
Off mode	P _{OFF}	0.009	kW	Rated heat output	P _{sup}	0,0	kW
Thermostat-off mode	P _{TO}	0.009	kW				
Standby mode	P _{SB}	0.009	kW	Type of energy input	Electric		
Crankcase heater mode	P _{CK}	0.042	kW				
<i>Other items</i>							

MODEL		QA-9				
Capacity control	Variable			Rated airflow (air-water)	4000	m ³ /h
Sound power level, indoors/outdoors	L _{WA}	- / 57	dB	Nominal heating medium flow		m ³ /h
Annual energy consumption	Q _{HE}	4710	kWh	Brine flow brine-water or water-water heat pumps		m ³ /h
Contact information	Qvantum Energi AB - Ji-te gatan 7 - 265 38 Åstorp - Sweden					

DRAFT

Index

B

Before installing
Transport [5](#)

E

Environmental information [4](#)

I

Important information
Environmental information [4](#)
Product labels [4](#)
Safety [3](#)
Serial number [4](#)

T

Transport [5](#)

DRAFT

QCH 2346-



123456

This publication presents information that was valid at the time of publishing.
Quantum reserves the right to make changes without prior notification.
Subject to possible printing errors.
©2023 Quantum Energi AB

DRAFT

HEAT PUMPS FOR SUSTAINABLE CITIES

WE CHANGE THE WAY THE CITIES OF EUROPE ARE HEATED

Quantum, founded in Sweden in 1993, develops high-quality heat pumps for individual buildings and innovative heat pump-based solutions for densely populated areas to enable everybody to benefit from emission free heating and cooling. The company has deep knowledge in both heat pump technology and energy systems engineering and works in close collaboration with engineering consultants, installers, project developers and utilities.

Quantum Energi AB

Ji-te gatan 7, 265 38 Åstorp – Sweden | quantum.com



Q V A N T U M