




# EPG2

## Control System and Menus



English - v0.99.1-0 - 20241028

# Table of Contents

A.1.1 Quick Start.....	3
A.2.1 Main page .....	3
A.3.1 Menu System .....	3
A.4.1 Event log.....	3
A.5.1 Warnings and Alerts .....	3
A.6.1 Statusbar.....	3
A.7.1 System Update.....	4
B.8.1 Regulation .....	5
B.8.2 Overtemp limit .....	6
B.8.3 Standard .....	7
B.8.4 Direct Power Control.....	8
B.8.5 UTK.....	10
B.9.1 Installation.....	11
B.9.2 Simulator .....	12
B.9.3 Fan and Pump .....	12
B.9.4 Load Limiter .....	13
B.9.5 Analog Input P20 .....	14
B.9.6 Analog Input P21 .....	15
B.9.7 Analog Output P18.....	16
B.9.8 Analog Output P19.....	17
B.10.1 Energy and Current.....	18
B.10.2 Power Groups .....	18
B.10.3 Busbar 1.....	19
B.11.1 User Interface .....	20
B.12.1 Communication .....	21
B.12.2 Reporting/Logging.....	22
B.12.3 Modbus.....	23
B.12.4 BACNet .....	24
B.13.1 Boiler info.....	25
B.13.2 Temperature sensors .....	26
B.13.3 Safety Interlocks.....	27
B.13.4 Other signals .....	28
B.13.5 Software Versions.....	28
B.13.6 Load Monitor .....	29
B.14.1 Administration.....	30
B.14.2 Software Updates .....	31
B.14.3 USB.....	32
B.14.4 Extra Features.....	32
A.15.1 Overview.....	4
B.15.2 Configuration .....	33

# Quick Start

Minimal steps to get the boiler started:

- Regulation mode
- Set Temperature
- Overtemperature limit
- Log and alerts

## Main page

None

## Menu System

None

## Event log

None

## Warnings and Alerts

### Simulator Active

alert\_simulator\_infotext

### Load Limiter Active

alert\_load\_limit\_infotext

### External Power Limit Active

alert\_external\_limit\_infotext

### Regulation is off

alert\_regulation\_off\_infotext

### Update current boards

One or more current meter boards can be updated.

Use the "Update" button in "Energy and Current/Busbar #"

### New Software available

A new version of the software is available.

Go to "Administration/Software Updates" to download and install.

### Check main breakers' torque

It is time to check the torque on the mains breaker cable clamps. Please refer to the technical manual for further instructions.

### Low Water Level

alert\_waterlevel\_infotext

### Overtemperature

alert\_overtemp\_internal\_infotext

### Boiler Temp. Sensor Missing

alert\_no\_temp\_sensor\_infotext

### PCB Temperature High

alert\_pcb\_temp\_infotext

### Boiler Temperature low

alert\_temp\_low\_infotext

### No UTK sensor connected

alert\_utk\_sensor\_infotext

### Forced Power Stage

alert\_force\_step\_infotext

### Overtemperature

alert\_overtemp\_external\_infotext

### Pressure High

alert\_pressure\_high\_infotext

### Load switch Off

alert\_breakers\_infotext

### Pressure Low

alert\_pressure\_low\_infotext

### Zero Voltage Protection

alert\_zero\_breaker\_sw\_infotext

### alert\_phase\_missing

alert\_phase\_missing\_infotext

### alert\_leakage\_current\_high

alert\_leakage\_current\_high\_infotext

## Statusbar

### BACNet

BACNet is enabled

### Log to cloud

Send logs to Värmebaronen

 **status\_dpc**  
status\_dpc\_infotext

 **Fan enabled**  
The fan is enabled and running

 **Modbus enabled**  
Modbus communication is enabled

 **Ethernet**  
Ethernet connection status

 **Pump enabled**  
Shows pump relay status

 **Screensharing**  
Indicates that screensharing is active

 **Indicates that the boiler simulator is active**  
status\_simulator\_infotext

 **SSL Certificates Missing**  
SSL Certificates used to secure communication with Värmebaronen AB's servers are missing. Please

contact Värmebaronen's service department to resolve.

 **USB Memory Drive**  
A USB memory drive is inserted

 **User level**  
I - Installer  
S - Service/admin  
P - Production

 **UTK**  
Outdoor temperature compensation mode selected

## System Update


Step by step guide for updating the system software

## Overview

None

# Regulation

Please note that Min-, Max- and standard values may vary depending on the boiler model and any accessories. Current values can always be read out directly on the boiler.




	info_text	default	min	max	mbid
<b>Actual Set Temp Used (°C)</b>	This is the value the boiler will actually use as set point. It is read from the selected Set Point Source below.				40102
<b>Set Point Source</b>	Select the set point source. "Internal" uses the value below. Also select this for control via modbus/BACNet "P20" and "P21" are analog inputs. Select input type under Installation. "UTK" uses the optional outdoor sensor together with an adjustable offset curve. See UTK under installation	internal			40101
<b>Boiler Set Value, internal (°C)</b>	Set point to use when Internal mode is enabled	60	10	85	40103
<b>Min. Set Temp (°C)</b>	Minimum value that can be selected above. This is also corresponds to an analog input of 0%	20	10	95	40104
<b>Max. Set Temp (°C)</b>	Maximum value that can be selected above. This is also corresponds to an analog input of 100%	95	10	95	40105
<b>External Power Limiting</b>	"Off" disables external power limiting. "Upper Limit" sets an upper limit that is used at next evaluation cycle (see the regulation method settings for timings). "Upper, fast down" enforces the limit immediately when changed.	off			40111
<b>Input Source</b>	Select the external limit source. "100%" is gives 100% maximum. "P20" and "P21" uses the analog inputs. "P32" is three bit binary from the expansion board. In the previous G1 series this was called EPVP and primarily used together with NIBE's heat pumps. "Net" is for modbus/BACnet.	none			40112
<b>External Signal in %</b>	The actual power limit level in %				40113

## Overtemp limit

The boiler's overtemperature protection should be set to trip a few degrees below the external overheating protection. When the overtemperature protection is activated, the contactors are shut off and a yellow warning shows. Normal regulation resumes when the boiler temperature has fallen below the hysteresis. Current limit value can be set to an absolute value or a relative value that follows Actual Setpoint

Used, up and down.




	info_text	default	min	max	mbid
<b>Overtemp mode</b>	The Overtemp limit can be set as Absolute Limit or Relative to Set Temp.	absolute			40121
<b>Absolute Limit (°C)</b>	The overtemp protection is triggered at this temperature.	85	0	95	40122
<b>Relative Offset (°C)</b>	Adds selected number of degrees (°C) to "Boiler Set Value" which is the Overtemp limit.	10	0	30	40123
<b>Hysteresis (°C)</b>	When the boiler temperature has decreased by the set number of degrees (°C) below the Overtemp limit normal regulation resumes.	5	1	10	40124

# Standard

In standard mode, the goal is to keep the boiler temperature as close to the setpoint as possible. The boiler regulates best if it is allowed to jump freely between available steps, but it is possible to limit the jump size if the installation requires it.

P,I and D values are factory set for each boiler size and may therefore differ from the values in the manual.



	info_text	default	min	max	mbid
<b>Max Power Step (kW)</b>	Maximum permissible power step. See the boiler's manual for more information about power/stage.	1080	0	1080	40141
<b>P (kW/ °C)</b>		4.8	0	20	40142
<b>I (W/ °C/s)</b>		17.3	0	100	40143
<b>D</b>		0	0	1000	40144

# Direct Power Control

DPC enables direct power control from a superior control system. In this mode, the internal temperature control is switched off. Overheating protection, maximum installed power and any external power limitation apply.

The following signal sources can be used:

- Internal. The desired value can be set directly on the display or via modbus/BACnet. This is the fastest control method.

- P20/P21. Control signal is taken from one of the analog inputs. These are configured separately.


When analog input is selected, the external control signal is run through a filter that does not pass the signal on until it has been stable at the same level for a certain time, normally 0.1s.

The control signal also goes through a hysteresis filter that switches only

when the signal has reached 2/3 to the next step.

To avoid overheating in the contactors, the minimum time interval between switching is normally 6s. Other times are available on request.

In some cases, it may be desirable to have a smooth ramp-up in steps. This is done by setting the maximum power jump up and down to less than the installed boiler power, as well as specifying a time interval for the change.



	info_text	default	min	max	mbid
<b>Signal Source</b>	Signal source for controlling the DPC power level. Select internal when using modbus and BACNet. If using P20/P21 these also need to be configured on their installation page.	internal			
<b>Power level (%)</b>		0	0	100	40132
<b>Max Power Step, up (kW)</b>	This limits the instantaneous change to a set level	1080	0	1080	40133
<b>Time between steps, up (s)</b>	This is the minimum time between steps when the boiler increases power.	12	6	900	40134
<b>Max Power Step, down (kW)</b>	This limits the instantaneous change to a set level	1080	0	1080	40135
<b>Time between steps, down (s)</b>	This is the minimum time between steps when the boiler decreases power.	12	6	900	40136
<b>Min. Update Interval(s)</b>		6	1	900	


# UTK

UTK mode allows the set point value to be adjusted in relation to the outside temperature.

A UTK-sensor must be connected to P13 in order for this function to work.

To enable, select UTK as Set Point Source in the main regulation settings.

Button on screen, or via modbus.



	info_text	default	min	max	mbid
<b>UTK - Outside Temperature Compensation</b>					
<b>Curve Offset (°C)</b>	This moves all the points up or down by the value entered	0	-10	10	40162
<b>Temperature Nodes (°C)</b>					
<b>-30</b>		63	20	80	40151
<b>-25</b>		62	20	80	40152
<b>-20</b>		60	20	80	40153
<b>-15</b>		57	20	80	40154
<b>-10</b>		53	20	80	40155
<b>-5</b>		49	20	80	40156
<b>0</b>		45	20	80	40157
<b>5</b>		40	20	80	40158
<b>10</b>		33	20	80	40159
<b>15</b>		27	20	80	40160
<b>20</b>		20	20	80	40161

# Installation

## installation\_helppage



	info_text	default	min	max	mbid
<b>Mode</b>	Select boiler control mode. "Off" disables all temperature control. "Standard" is the default, predictive temperature control method. "DPC", Direct Power Control, lets an external control system regulate the power. Available options depends on ordered configuration	off			40201
<b>Boiler Simulator</b>	Turn on or off the internal boiler simulator. The simulator can be used for demoing and is useful for testing input and output signals before deploying the boiler.	off			40202
<b>Installed Power, kW</b>	Limit the boiler to a lower power. The selected level will be considered as 100%	1080	0	1080	40203
<b>Enable Soft Zero Voltage Protection</b>	With this enabled the boiler won't automatically restart the regulator after a power outage or reboot. The user is required to acknowledge the alert on the display. The alert can only be acknowledged by physically being present at the boiler.	0			

# Simulator


simulator\_helppage



	info_text	default	min	max	mbid
<b>Restart</b>		Restart			40211
<b>Initial temperature</b>		25	1	100	40212
<b>System Volume(l)</b>		1000	1	15000	40213
<b>Heating Power Load(kW)</b>		5	0	1500	40214
<b>System delay(s)</b>		0	0	900	40215

# Fan and Pump

fan\_and\_pump\_helppage



	info_text	default	min	max	mbid
<b>Fan enabled</b>		1			40131
<b>Start Temperature (°C)</b>		40	5	60	40232
<b>Start when contactors are active</b>		True			40235
<b>Pump</b>		off			40241

# Load Limiter


None



	info_text	default	min	max	mbid
<b>Sensor type</b>	Direct modes uses one set of transformers. Secondary mode uses primary transformers at the fuses and secondary to the boiler	off			40221
<b>Main Breaker(A)</b>		160	1	1000	40222
<b>Breaker Margin(A)</b>		10	1	1000	40223
<b>Primary Transformer Ratio</b>	Primary transformer ratio. Example: A stated ratio of 300:5 on the transformers gives 60.	400	1	1000	40224
<b>Cable Length(m)</b>		0	0	250	40225
<b>Cable area(mm²)</b>		0.5	0.5	15	40226
<b>Phase 1 Current (A)</b>					40227
<b>Phase 2 Current (A)</b>					40229
<b>Phase 3 Current (A)</b>					40230

# Analog Input P20


analog\_input\_p20\_helppage



	info_text	default	min	max	mbid
<b>Input Type</b>		off			40251
<b>Scaled Value (%)</b>		0			40252
<b>Raw Input (V)</b>		0			40253
<b>Lower Limit (V)</b>		0	0	10	40254
<b>Upper Limit (V)</b>		10	0	10	40255
<b>Raw Input (mA)</b>		0			40256
<b>Lower Limit (mA)</b>		4	0	20	40257
<b>Upper Limit (mA)</b>		20	0	20	40258
<b>Manual Level (%)</b>		0	0	100	40259

# Analog Input P21


analog\_input\_p21\_helppage



	info_text	default	min	max	mbid
<b>Input Type</b>		off			40261
<b>Scaled Value (%)</b>		0			40262
<b>Raw Input (V)</b>		0			40263
<b>Lower Limit (V)</b>		0	0	10	40264
<b>Upper Limit (V)</b>		10	0	10	40265
<b>Raw Input (mA)</b>		0			40266
<b>Lower Limit (mA)</b>		4	0	20	40267
<b>Upper Limit (mA)</b>		20	0	20	40268
<b>Manual Level (%)</b>		0	0	100	40269

# Analog Output P18


analog\_output\_p18\_helppage



	info_text	default	min	max	mbid
<b>Output Type</b>		off			40271
<b>Output Value (%)</b>		0			40272
<b>Output Value (V)</b>		0			40273
<b>Lower Limit (V)</b>		0	0	10	40274
<b>Upper Limit (V)</b>		10	0	10	40275
<b>test_value</b>		0	0	100	40276
<b>Signal Source</b>		off			40277
<b>Temp. Low End</b>		-10	-10	100	40278
<b>Temp. High End</b>		110	50	160	40279

# Analog Output P19


analog\_output\_p19\_helppage



	info_text	default	min	max	mbid
<b>Output Type</b>		off			40281
<b>Output Value (%)</b>		0			40282
<b>Output Value (V)</b>		0			40283
<b>Lower Limit (V)</b>		0	0	10	40284
<b>Upper Limit (V)</b>		10	0	10	40285
<b>test_value</b>		0	0	100	40286
<b>Signal Source</b>		off			40287
<b>Temp. Low End</b>		-10	-10	100	40288
<b>Temp. High End</b>		110	50	160	40289

# Energy and Current


## energy\_helppage



	info_text	default	min	max	mbid
<b>Active Power (kW)</b>					
<b>Current (A)</b>					
<b>Power Step</b>					

# Power Groups


This page shows the number of times the relays controlling the power groups have operated.



	info_text	default	min	max	mbid
<b>power_group_operations</b>					
<b>Relay 1</b>					40411
<b>Relay 2</b>					40412
<b>Relay 3</b>					40413
<b>Relay 4</b>					40414
<b>Relay 5</b>					40415
<b>Relay 6</b>					40416

# Busbar 1

## eprog\_1\_helppage



	info_text	default	min	max	mbid
<b>Total Current (A)</b>	Total current of this busbar, in Amperes				40421
<b>Phase 1 Current (A)</b>					40422
<b>Phase 2 Current (A)</b>					40423
<b>Phase 3 Current (A)</b>					40424
<b>Serial number</b>					
<b>Hardware version</b>					
<b>Firmware version</b>					
<b>Available fw version</b>					
<b>Update Status</b>					
<b>Load Hex File to Board</b>		A			
<b>Board Enabled</b>		False			40426
<b>Identify Board</b>		False			
<b>eprog_phase_1_k</b>					
<b>eprog_phase_1_m</b>					
<b>eprog_phase_2_k</b>					
<b>eprog_phase_2_m</b>					
<b>eprog_phase_3_k</b>					
<b>eprog_phase_3_m</b>					
<b>eprog_leakage_k</b>					
<b>eprog_leakage_m</b>					
<b>test_version</b>					

# User Interface


## user\_interface\_helppage



	info_text	default	min	max	mbid
<b>Language</b>		swedish			40301
<b>Date</b>		A			
<b>Time</b>		A			
<b>Time Zone</b>		GMT+1			
<b>Format</b>		24h			
<b>Date Format</b>		YYYY-MM-DD			
<b>Use NTP</b>	Network Time Protocol Enable to automatically synchronize the clock will with the selected time server	True			
<b>NTP server</b>	A valid URI to the NTP server.	ntp.ubuntu.com			
<b>Display Timeout(s)</b>	After this long time of inactivity the system goes back to the main page and the display dims. Active warnings and errors will cause the backlight to blink.	300	30	7200	

# Communication


## communication\_helppage



	info_text	default	min	max	mbid
<b>Network Status</b>					40501
<b>DCHP Mode</b>		auto			40502
<b>IP Adress/Prefix</b>	The ethernet IP adress should be in the following format: Aaa.bbb.ccc.ddd/pp where pp is the prefix, usually 24	192.168.1.2/24			
<b>Gateway</b>		192.168.1.2			
<b>DNS Server 1</b>		192.168.1.2			
<b>DNS Server 2</b>		192.168.1.2			
<b>MAC address</b>					

# Reporting/Logging

## reporting\_helppage




	info_text	default	min	max	mbid
<b>Send logs to Värmebaronen</b>	Enable this option to periodically send logs to Värmebaronen. This allows Värmebaronen to improve the performance and functions of the boiler and helps the service department solve issues faster. The connection is secured with SSL, like all modern web pages, and does not allow external control of the boiler. This requires that the boiler has a working connection to internet. This is required in order to send alarms to email.	False			
<b>Active</b>		False			
<b>Recipient</b>		email@test.com			
<b>Active</b>		False			
<b>Recipient</b>		email@test.com			
<b>Active</b>		False			
<b>Recipient</b>		email@test.com			
<b>Active</b>		False			
<b>Recipient</b>		email@test.com			

# Modbus

The optional modbus module allows controlling and monitoring parameters via RS485 or ethernet.


 Decimal numbers are written and read as ten times larger. Ex. 46.7°C reads as 467



	info_text	default	min	max	mbid
<b>Mode</b>	Select communication medium: - RTU uses RS485 on connector P22. - TCP uses ethernet on connector P26	off			
<b>Device ID</b>		99	1	254	
<b>TCP Port (TCP)</b>					
<b>Baud Rate (RTU)</b>		9600			
<b>Parity</b>		none			
<b>Stop Bits</b>		1			
<b>Test field, 0xABCD = 43981</b>					40511
<b>Test field, read/write</b>		0	0	100	40512

## BACNet

The optional BACNet module allows controlling and monitoring parameters via a network connection.



The screenshot shows a HVAC control interface with a sidebar menu and a main configuration table.

**Sidebar Menu:**

- > Regulation
- > Installation
- > Energy and Current
- User Interface
- Communication
  - Reporting/Logging
  - Modbus
  - BACNet** (highlighted)
- > Boiler info

**Top Bar:**


- House icon
- Gear icon
- Document icon
- 21°C (65°C)  
0kW
- Network icon
- Green circle icon
- Blue circle icon
- DPC icon
- 16:11:00
- 2024-10-28
- Camera icon

**Table:**

	info_text	default	min	max	mbid
<b>enabled</b>		False			

# Boiler info


## product\_helppage



	info_text	default	min	max	mbid
<b>Model</b>					
<b>SKU</b>		5836-1			
<b>Boiler Serial Number</b>					
<b>CPU Serial Number</b>					
<b>Main board version</b>					
<b>System Software Version</b>					
<b>Total System Uptime (h)</b>					
<b>IP Adress/Prefix</b>	The ethernet IP adress should be in the following format: Aaa.bbb.ccc.ddd/xx where xx is the prefix, usually 24				

# Temperature sensors


This page shows all connected temperature sensors



	info_text	default	min	max	mbid
<b>P10, Boiler</b>					40002
<b>P11, Ambient</b>					40003
<b>P12, Secondary</b>					40004
<b>P13, UTK</b>					40005
<b>P14, Boiler HT</b>					40006
<b>P15, Secondary HT</b>					40007
<b>P36, PT100</b>					40008
<b>P37, PT100</b>					40009
<b>P38, NTC</b>					40010
<b>P39, NTC</b>					40011
<b>PCB, Interior</b>					40012
<b>Relative Humidity, %</b>					40013

# Safety Interlocks


interlocks\_helppage



	info_text	default	min	max	mbid
<b>P17.</b> <b>Water Level OK</b>		False			40021
<b>P4:2.</b> <b>Reserved</b>		False			40022
<b>P4:3.</b> <b>Overtemp OK</b>		False			40023
<b>P4:4.</b> <b>Pressure sensor. high OK</b>		False			40024
<b>P5:2.</b> <b>Main breakers closed</b>		False			40025
<b>P5:3.</b> <b>Pressure sensor. low OK</b>		False			40026
<b>P5:4.</b> <b>Reserved</b>		False			40027

## Other signals


other\_ios\_helppage



	info_text	default	min	max	mbid
<b>Live LED</b>		False			
<b>Expansion bus 5V</b>		False			40031
<b>Expansion bus 12V</b>		False			40032
<b>P32:2. Expansion board</b>		False			40028
<b>P32:3. Expansion board</b>		False			40029
<b>P32:4. Expansion board</b>		False			40030

## Software Versions


software\_versions\_helppage



	info_text	default	min	max	mbid
<b>Software Versions</b>					

# Load Monitor


load\_monitor\_helppage



	info_text	default	min	max	mbid
<b>Phase 1 Current (A)</b>					
<b>Phase 2 Current (A)</b>					
<b>Phase 3 Current (A)</b>					

# Administration


## admin\_helppage



	info_text	default	min	max	mbid
<b>Current User Level</b>		0			
<b>Switch to Standard</b>		A			
<b>Switch to Installer</b>		A			
<b>Switch to VB Service</b>		A			
<b>Switch to Production</b>		A			
<b>Stream screenshots</b>	When enabled, this will allow the boiler to send a live stream of screenshots to Värmebaronen Service to help installation and troubleshooting. The streaming automatically turns off 20min after the display dims. This requires a working internet connection.	False			

# Software Updates


## software\_update\_helppage



	info_text	default	min	max	mbid
<b>Current System Software Version</b>					
<b>Start Update...</b>		A			
<b>Update Status</b>					
<b>Available version</b>					
<b>Git hash</b>					
<b>Image build time</b>					
<b>Git status</b>					
<b>Active Partition</b>					
<b>Check for network update</b>		A			
<b>Start Update...</b>		A			

# USB

## usb\_helppage



	info_text	default	min	max	mbid
<b>Copy configuration to USB</b>		A			
<b>Restore configuration from USB</b>		A			
<b>Screenshot Count</b>					
<b>Copy to USB</b>		A			
<b>Delete all screenshots</b>		A			
<b>Backup Logs</b>		A			

# Extra Features


## software\_features\_helpage



	info_text	default	min	max	mbid
<b>DPC Regulation</b>	Set if DPC mode is available				
<b>ModBus Support</b>	Set if modbus is available				
<b>BACNet</b>	Set if BACNet is available				

# Configuration

## configuration\_helppage



	info_text	default	min	max	mbid
<b>Backup to USB</b>		A			
<b>Restore from USB</b>		A			
<b>Factory Reset</b>		A			